

Clear Magic Stick

Benefits

This perfectly transparent stick obtained thanks to EstoGel® Max adapts to the shade of the lips to beautify them.



PHASE	RAW MATERIAL	%
A	EstoGel® Max	50,00
A	Coco-Caprylate Caprate	27,60
A	Castor Oil	7,00
A	Isoamyl Laurate	7,00
B	Castor Oil	7,80
B	CI 45380	0,20
B	Citric Acid	qsp
C	Fragrance	0,40

Process

- Prepare in advance a premix of B
- Mix EstoGel® Max with the oils for 30 minutes at 85°C with a rotor stator in the main beaker
- Add B to A under stirring
- Cool to 80°C
- Add the fragrance and homogenize
- Pour into a suitable mold