

Clear Perfumed Gel

Benefits



- ExpertGel® helps perfume last longer
- Thick gel with shape memory
- Perfectly transparent, concentrated fragrance formula

PHASE	RAW MATERIAL	%
A	Demineralized Water	31,05
A	ExpertGel® EG312	3,45
B	Demineralized Water	52,55
B	EDTA	0,05
C	Fragrance	4,00
C	Solubilizer (660352)	8,20
C	SymDiol® 68	0,70

Process

- Prepare in advance a solution of ExpertGel® EG312 in water
- Introduce B in the main beaker and solubilize EDTA in water
- Premix C and add it slowly to B under gentle stirring
- Add A to B+C under gentle stirring until the blend is homogeneous