

# Click Pen Tonka

## Benefits



- Fragrance formulated without alcohol
- An oily gel structured with EstoGel® Green that does not drip into the packaging
- A new way to apply fragrance with a non-greasy, non-sticky formula

PHASE	RAW MATERIAL	%
A	EstoGel® Green	5,00
A	Coco-Caprylate Caprate	57,50
A	Caprylic/Capric Triglyceride	7,50
A	Undecane (and) Tridecane	10,00
A	Fragrance	20,00

## Process

- Introduce A in the main beaker and heat up to 80°C under stirring
- At 80°C, stir for 20 min
- Cool to 70°C, add B and stir for 10 min
- Cool to 40°C, add C and stir for 10 min
- Cool to 35°C and pour into a click pen