

Incredible Rich Cream

Benefits

- Thermogelling properties
- Emulsion stabilizer
- Soft and silky touch



PHASE	RAW MATERIAL	%
A	Demineralized Water	60,18
A	EDTA	0,02
A	Phenoxyethanol	0,60
A	Glycerin	5,00
A	Propanediol	3,00
B	Sepinov™ EMT 10	0,80
C	Caprylic/Capric Triglyceride	10,00
C	Fragrance	0,20
D	Demineralized Water	18,00
D	ExpertGel® EG312	2,00

Process

- Prepare D in advance solubilizing ExpertGel® in water at room temperature for 1 hour
- Add A in the main beaker and solubilize EDTA
- Disperse B in A until the gel is perfectly homogeneous
- Emulsify for 10 minutes adding C into A+B
- Add the premix D in the gel cream and blend