

Lip Tint

Benefits



- Unlike standard lip inks, this product does not dry out the lips
- ExpertGel® ensures perfect definition of the product on the lips
- No migration of the colour into fine lines.

PHASE	RAW MATERIAL	%
A	Demineralized Water	58,00
A	Euxyl® PE 9010	0,80
A	Alcohol	5,00
A	Glycerin	5,00
A	Demineralized Water	25,00
B	ExpertGel® EG312	3,50
C	CI 17200	0,20
C	Tween® 20	2,00
D	Fragrance	0,50

Process

- Prepare a premix with the ingredients of the phase B, stir slowly at room temperature until ExpertGel® is fully solubilized
- Introduce the ingredients of the phase A in the main beaker and homogenize
- Add B to A and homogenize
- Add C once the blend is perfectly homogeneous and uniform