

Natural Foundation

Benefits

- Pleasant, easy-to-spread texture thanks to EstoGel® Green
- Very even skin finish
- Stabilization of the W/O emulsion



PHASE	RAW MATERIAL	%
A	Demineralized Water	55,00
A	Sodium Chloride	1,00
A	Glycerin	3,00
B	EstoGel® Green	2,00
B	Caprylic/Capric Triglyceride	10,00
B	Undecane (and) Tridecane	9,50
B	Polyhydroxystearic Acid	0,50
B	NWD-8462 Titanium Dioxide	13,32
B	NWD-9336 Yellow Iron Oxide	1,12
B	NWD-7336 Red Iron Oxide	0,43
B	NWD-2336 Black Iron Oxide	0,13
C	Polyglyceryl-3 Diisostearate	2,00
C	Polyglyceryl-2 Dipolyhydroxystearate	2,00
D	Fragrance	0,50

Process

- In a secondary beaker, introduce A and solubilize NaCl
- In the main beaker, introduce B and heat up to 80°C under stirring
- At 80°C, stir for 30min
- Cool down to 40°C
- Add C to B and stir for 5 min
- Make the emulsion pouring A into B+C for 15 min
- Add D and homogenize