

Rouge Vinyle

Benefits

An ultra shiny lipstick without wax with a very melting and glide-on application.



PHASE	RAW MATERIAL	%
A	EstoGel® Max	55,00
A	COD-8002 D&C Red 6 Ba Lake	3,20
A	COD-8001 D&C Red 7 Ca Lake	12,80
A	Caprylic/Capric Triglyceride	23,40
A	Hazelnut Oil	5,00
B	Fragrance	0,60

Process

- Mix EstoGel® Max with the oils for 30 minutes at 85°C with a rotor stator
- Cool to 80°C
- Add the fragrance and homogenize
- Pour into a suitable mold