

Peel Off Mask

Benefits

- The mask is very soft and easy to remove



Phase	Trade name	INCI name	Supplier	%
A	Demineralized Water	Water	-	30.00
A	Mowiol 23-88	Polyvinyl Alcohol	-	10.00
B	Demineralized water	Water	-	21.25
B	ExpertGel® EG312	Poloxamer 338 (and) PPG-51/SMDI Copolymer	PolymerExpert	3.00
B	Alcohol Denat	Alcohol	-	20.00
C	EDTA	Disodium EDTA	-	0.05
D	Glycerin	Glycerin	-	10.00
D	Propylene Glycol	Propylene Glycol	-	5.00
E	Parfum	Fragrance	H.Reynaud & Fils	0.20
E	Emulgin CO 40	PEG-40 Hydrogenated Castor Oil	BASF	0.50

Process

- Heat 30% of the water phase up to 60°C then swell Mowiol and mix slowly until homogeneous, cool down to RT
- Prepare ExpertGel® solution by adding 21.25% of cold water, 20% of ethanol, and swell ExpertGel®
- Add EDTA to the ExpertGel® solution, then add glycols
- Add the mix fragrance/solubilizer
- Then add very slowly the Mowiol solution and mix until homogenous